



Normal lengths:
 Swiss round cylinder 32.5/32.5
 Euro cylinder 30/30
 Measurements in mm

Measurements in mm. Choose 100 % for a printout!
 Check conformity with a ruler.



Measuring gauge for ekey lock

1. Fold and break off the measuring gauge. Shove it into the opening, instead of the cylinder. Bolt it down with the screw.
2. Read the cylinder length you need on both sides. Beware: the A measurement is outside!
3. Add the fitting length to this measurement and round up to the next 5 mm. Beware: the knob must move freely on both sides!

